

Mod. R&S. 05/0 Pag. 1/1

Last Updating: 10/2008

# P.S. ELECTRIC

## Description

PVC-free material, with vibrant surface, for Cad-Cut ® applications. Backing: adhesive polyester.

### **Basic Information**

Due to the many different base materials available on the market, the following heat transfer instructions are given as guideline only:

Temperature: 150°C

Time: 15"
Pressure: min.

## **Application Instructions**

- 1) Cut the material in reverse
- 2) Weed the exceeding material (for an easier weeding, we suggest to leave the cut material on a hot surface  $60/70^{\circ}$ C for a few seconds)
- 3) Place the material on the garment with its polyester support
- 4) Heat apply
- 5) Remove polyester backing hot

### Suitable for

Cotton, polyester, poly-cotton blends.

Not suitable for treated and dyed garments (sublimation inks)

Washing: (wait 24h after the heat transfer)

60°C Max. – do not use bleach or other aggressive chemical agents

**Dry-cleaning:** no **Tumble drier:** yes

N.B.: all information given in this sheet are based on our experience

We recommend to always perform a test before starting standard production

The product meets the Italian and Ue regulations relating to its proper use. This document can be subject to variations. Updated versions are available on our website <a href="www.siser.it">www.siser.it</a>. For further information, please contact our Sales Office. Thank you.







